PCG-VX89/VX89K/VX89P

Illust: PCG-VX89P

SERVICE MANUAL

Ver 1-2002J

Revision History

Lineup: PCG-VX89P PCG-VX89K PCG-VX89

For American Area

US Model Canadian Model







· Design and specifications are subject to change without notice.

NOTEBOOK COMPUTER

SONY

Information in this document is subject to change without notice.

Sony, VAIO and CLIE are trademarks or registered trademarks of Sony. Microsoft, Windows, Windows Media, Outlook, Bookshelf and other Microsoft products are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries. The word Bluetooth and the Bluetooth logo are trademarks of Bluetooth SIG, Inc. AMD, AMD logo, AMD Duron and combinations thereof, 3DNow!, are trademarks of Advanced Micro Devices, Inc. Intel Inside logo, Pentium and Celeron are trademarks or registered trademarks of Intel Corporation. Transmeta, the Transmeta logo, Crusoe Processor, the Crusoe logo and combinations thereof are trademarks of Transmeta Corporation in the USA and other countries. Graffiti, HotSync, PalmModem, and Palm OS are resistered trademarks, and the Hotsync logo and Palm are trademarks of Palm, Inc. or its subsidiaries. (M) and Motrola are trademarks of Motrora, Inc. Other Motrola products and services with (R) mark like Dragomball are the trademarks of Motrola, Inc.

All other names of systems, products and services in this manual are trademarks or registered trademarks of their respective owners. In this manual, the (TM) or (R) mark are not specified.

<u>Caution Markings for Lithium/Ion Battery</u> - The following or similar texts shall be provided on battery pack of equipment or in both the operating and the service instructions.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

CAUTION: The battery pack used in this device may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 100°C (212°F) or incinerate.

Dispose of used battery promptly.

Keep away from children.

CAUTION: Changing the back up battery.

- Overcharging, short circuiting, reverse charging, multilation or incineration of the cells must be avoided to prevent one or more of the following occurrences; release of toxic materials, release of hydrogen and/or oxygen gas, rise in surface temperature.
- If a cell has leaked or vented, it should be replaced immediately while avoiding to touch it without any protection.

Service and Inspection Precautions

1. Obey precautionary markings and instructions

Labels and stamps on the cabinet, chassis, and components identify areas requiring special precautions. Be sure to observe these precautions, as well as all precautions listed in the operating manual and other associated documents.

2. Use designated parts only

The set's components possess important safety characteristics, such as noncombustibility and the ability to tolerate large voltages. Be sure that replacement parts possess the same safety characteristics as the originals. Also remember that the \triangle mark, which appears in circuit diagrams and parts lists, denotes components that have particularly important safety functions; be extra sure to use only the designated components.

3. Always follow the original design when mounting parts and routing wires

The original layout includes various safety features, such as inclusion of insulating materials (tubes and tape) and the mounting of parts above the printer board. In addition, internal wiring has been routed and clamped so as to keep it away from hot or high-voltage parts. When mounting parts or routing wires, therefore, be sure to duplicate the original layout.

4. Inspect after completing service

After servicing, inspect to make sure that all screws, components, and wiring have been returned to their original condition. Also check the area around the repair location to ensure that repair work has caused no damage, and confirm safety.

5. When replacing chip components...

Never reuse components. Also remember that the negative side of tantalum capacitors is easily damaged by heat.

6. When handling flexible print boards...

- The temperature of the soldering-iron tip should be about 270C.
- Do not apply the tip more than three times to the same pattern.
- Handle patterns with care; never apply force.

Caution: Remember that hard disk drives are easily damaged by vibration. Always handle with care.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!


LES COMPOSANTS IDENTIFÉS PAR UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈSES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPÉMENTS PUBLIÉS PAR SONY.

TABLE OF CONTENTS

Section	<u>Title</u>	<u>Page</u>
CHAPTER 1.	BLOCK DIAGRAM	1-1 (to 1-2)
CHAPTER 2.	FRAME HARNESS	DIAGRAM 2-1 (to 2-2)
CHAPTER 3.	EXPLODED VIEWS	
	PARTS LIST	
3-1. Main Section	n	3-2
3-2. LCD Sectio	n – Made by HI –	3-5
		(to 3-6)

History of the changes is shown as the "Revision History" at the end of this data.


CHAPTER 1. BLOCK DIAGRAM



1-2 (END)

CHAPTER 2.

FRAME HARNESS DIAGRAM



2-2 (END)

EXPLODED VIEWS AND PARTS LIST

NOTE:

- · Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- When two or more parts are shown in parallel, use the part described first as the main part.
- The parts marked "\$" are the High Value Modules. The parts marked "#" are the parts on which barcode label is attached.


The components identified by mark $\ensuremath{\Delta}$ or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque ${\it \triangle}$ sont critiques pour la sécurité.


Ne les remplacer que par une pièce portant le numéro spécifié.

3-1. Main Section

Ref.No.	Part No.	Description	Ref.No.	Part No.	Description
2	1-477-283-21 \$ # 4-662-400-02 1-796-319-11 4-666-738-21 4-666-738-31	KEYBOARD UNIT (US) COVER (TP) PAD, TOUCH (VX89P)LABEL (ID) (VX89)LABEL (ID)	63 64 * 65 66 67	4-662-573-02 4-662-574-02 4-662-570-02 1-761-380-23 1-685-170-11	SPACER (WL) SWITCH (WL) BRACKET (IO L) CARD, MODEM FPC (MDC)
4 5 6 7 8	4-666-738-41 4-663-835-01 4-657-945-01 4-662-405-02 X-4624-713-6	(VX89K)LABEL (ID) TAPE (TP) PLATE (TP) ESCUTCHEON (JOG) HOUSING (PARM REST) ASSY	* 68 69 70 71 * 72	4-662-665-02 1-684-994-11 1-816-580-11 4-643-832-41 4-662-664-02	PLATE (PCC) FPC (PC CARD, WITH CONNECTOR) CONNECTOR, PC CARD (EJECTOR) DUMMY CARD PROTECTOR (PCC)
9 10 11 12 13	4-662-787-01 A-8067-219-A 4-662-421-02 1-825-150-21 4-658-789-02	CUSHION (CENTER BZ) COMPLETE PWB SWX-103 CASE (CAPS) SPEAKER, (2.0CM) TAPE (HARNESS)	73 74 75 77 78	4-663-422-01 4-663-421-02 1-761-495-11 4-664-890-02 4-664-957-01	SHEET (FPC MDC) SHEET (MPCI) CARD, WIRELESS LAN CUSHION HEATSINK SHEET KEYBOARD
14 15 16 17 18	4-663-133-01 1-824-088-11 1-824-085-11 1-824-089-11 X-4624-886-2	HOLDER (SP) (R) CABLE, FLEXIBLE FLAT (SWX1-SWX2 CABLE, FLEXIBLE FLAT (MBX-SWX1) CABLE, FLEXIBLE FLAT (SWX1-TP) PARM ASSY, LATCH	81 82 83 84 85	4-665-008-01 4-665-009-01 4-664-909-01 4-663-932-01 4-664-221-01	SHEET (SP) TAPE (MPCI) SHEET (BRACKET R) SHEET (DC), INSULATING SHEET (MBX), INSULATING
21 22 23 24 25	4-662-407-01 1-476-945-11 A-8067-218-A 4-663-132-01 1-825-150-11	ENCODER, JOG COMPLETE PWB SWX-101	86 87 88 89 90	4-664-224-01 4-660-499-11 4-657-991-01 4-664-253-02 4-664-254-02	SHEET (FFC 30) CUSHION DOOR SHEET (JOG), INSULATING PLATE (WL) SHEET (HDD), CONDUCTIVE
29	4-662-918-01 1-763-838-11 A-8112-160-A \$ # 1-468-624-21 4-662-925-01	PROTECTER HEATSINK DC FAN (WITH HEATSINK) C/P (MBX-56) (P900) (S) BATTERY, VANADIUM-LITHIUM DC, HOLDER	91 92 97 98 99		SHEET (PC CARD) PLATE (MINI-PCI) ASSY PLATE (KEYBOARD) CUSHION (PKB) CUSHION MZ
32 33 34 * 35 36	1-961-483-21 1-960-827-71 A-8067-207-A 4-662-571-01 X-4624-779-2	HARNESS (WITH DC JACK) HARNESS (2 PIN) COMPLETE PWB CNX-174 BRACKET (IO R) ASSY DOOR R	100 101 104 105 106	4-665-096-01 4-664-828-01 A-8067-505-A 1-961-895-11 4-666-382-01	TAPE (COVER TP) ADHESIVE TAPE (BOTTOM) COMPLETE PWB FLT-7 HARNESS ADHESIVE (TAPE) (FLT-7)
37 38 39 40 41	1-824-086-11 4-663-369-02 4-662-877-02 1-824-087-11 A-8067-544-A \$	CABLE, FLEXIBLE FLAT (MBX-CNX) COVER (R), FOOT RUBBER (REAR), FOOT CABLE, FLEXIBLE FLAT (CNX-IFX) COMPLETE PWB IFX-207	B1 B2 B3 B4 B5	4-664-453-01 4-664-453-11 4-641-726-21 4-635-966-01 4-635-301-01	SCREW (M2X4), SPECIAL HEAD SCREW (M2X5.5), SPECIAL HEAD SCREW (M2), SPECIAL HEAD SCREW (HEX) SCREW M3X4
42 43 44 46 47	4-662-878-02 X-4624-811-2 4-659-832-01 4-635-956-01 4-663-370-02	RUBBER (FRONT), FOOT HOUSING (BOTTOM) ASSY SHEET,THERMAL SPRING (B), COMPRESSION COIL COVER (L), FOOT			
48 49 * 50 51 52	4-663-438-02 X-4624-888-2 4-662-388-02 4-664-157-01 A-8059-344-A \$ #	SHEET DOOR (HDD) ASSY BRACKET (HDD) SHEET (HDD) ASSY HDD 30GB (T,20,F)(S)			
53 54 55 56 57	1-685-027-11 1-684-993-11 X-4624-780-4 A-8067-204-A 1-961-763-11	PWB, FLEXIBLE PRINT (HDD) FPC (VGA) ASSY DOOR V COMPLETE PWB CNX-176 HARNESS, RJ-45			
* 58 59 60 61 62	4-662-572-01 1-791-608-21 A-8067-205-A X-4624-781-4 1-684-986-11	BRACKET (IO V) CONNECTOR, HARNESS WITH (DC) COMPLETE PWB CNX-173 ASSY DOOR L FPC (I. LINK)			



3-2. LCD Section – Made by HI –



3-5

201 202 203 204	Part No. 4-662-789-01 X-4624-714-2 4-662-788-01 4-662-787-01 4-659-342-01	Description COVER (LCD), SCREW HOUSING (BEZEL) ASSY CUSHION, LATCH CUSHION (CENTER BZ) BLIND (LCD), SCREW
208 * 209 210	4-662-427-01 A-8067-411-A \$ # 4-662-434-01 1-961-709-11 4-658-789-02	BRACKET (LCD L) LCD(14HI)ASSY (S) BRACKET (LCD R) HARNESS, LCD TAPE (HARNESS)
213 214	A-8067-221-A 1-823-844-21 X-4624-887-1 4-639-623-01 A-8067-220-A	CABLE, COAXIAL (BLACK) (L670) DISPLAY ASSY, LATCH
219 220 221	1-823-844-31 X-4624-812-2 X-4624-716-2 4-662-383-02 X-4624-717-2	CABLE, COAXIAL (GRAY) (L930) HOUSING (DISPLAY) ASSY HINGE (RIGHT) ASSY COVER (HINGE) (R) HINGE (LEFT) ASSY
223 224 227	4-662-382-02 1-476-735-11 X-4625-019-1	COVER (HINGE) (L) INVERTER UNIT ESCUTCHEON (WL) ASSY
B2 B3		SCREW (M2X4), SPECIAL HEAD SCREW (M2X4), SPECIAL HEAD SCREW (M2), SPECIAL HEAD SCREW (M2), SPECIAL HEAD

Ref.No.	Part No.	Description ACCESSORIES ************************************
<u></u> 802 804 805	1-476-943-21 \$ 1-757-562-31 1-823-439-11 4-657-363-01 X-4625-087-1	ADAPTOR, AC CORD, POWER CORD, ILINK CONNECTION CLAMP STAND ASSY
807	A-8110-748-A 4-668-323-01 4-667-818-01	BP2S/HI (U) ASSY (S) (VX89K) SPECIFICATION SHEET, 2370UAZ QUICK START, 2370UA
LOOK AT EXPLODED VIEWS OF THE PART		
808		PCGA-CRWD2

The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.



802



Power Cord (1)

805 Clamp (1)



806 Stand (1)



i LINK Connection Cord (1) Battery Pack (1)





CD-RW/DVD-ROM Drive (PCGA-CRWD2)



- The CD-RW/DVD-ROM Drive itself does not have the Part No. Refer to the PCGA-CRWD2 Service manual (9-874-566-01). Because only the 804 iLINK Connection Cord is reguired for connection with a computor, the following parts are not supplied with the CD-RW/DVD-ROM drive.

 - 1-476-940-22 ADAPTOR, AC 1-757-562-31 CORD, POWER
 - 1-790-763-21 CORD, CONNECTION

 - 4-663-161-11 MANUAL, INSTRUCTION
 - 4-663-751-11 MANUAL, INSTRUCTION (FIRST)

Confidential



List of PCG-VX Series (As of October, 2002)

Model Name	Service Manual Part No.	
PCG-VX88 PCG-VX88P	9-874-532-01	
PCG-VX89 PCG-VX89K PCG-VX89P	9-876-021-01	



This manual and the constituent data may not be replicated, copied nor reprinted in whole or in part without prior written authorization of Sony Corporation.

Revision History

Suffix	Ver.	Date	Contents	QM No.
-01	Ver. 1	2002.10.04	First Edition	
	< Remar	ks >		